

ASSEMBLY INSTRUCTIONS

ITEM CODE : IN 4397

ITEM DESCRIPTION : 2 DRAWER CONSOLE

1

Reverse the console top & place the leg as shown & align the leg to match the apron.



Insert the Bolt to fix the leg with the console top and tighten the nut with the washer as shown in fig1

2



3

Fix the other pair of leg in the similar way





Fig. 1



Reverse the console straight. Now your console is ready for use.

4



"INSTRUCTIONS DE MONTAGE"

1

Retournez l'unité, placez le pied comme indiqué et alignez-le pour qu'il corresponde à la jupe.




Insérez le boulon pour fixer le pied à la partie supérieure de l'unité, puis serrez l'écrou avec la rondelle comme indiqué sur la figure 1.

2



3

Fixez l'autre paire de pieds de la même manière.



Redressez l'unité. Votre meuble est maintenant prêt à être utilisé.

4



Fig. 1

