

## LED Outdoor String Lights

Please read this manual carefully to ensure safe and optimal performance.

### Specifications:

Distance between two bulbs: 19.7 inches.

Total length of the string lights: 16.4 ft.

Bulb type: S12.

Connectable string lights: **Maximum of 3 strings** can be connected together.

IP44 waterproof rating: Protected against water splashes from any direction.



### Safety Instructions:

- Carefully inspect the string lights for any damage before use. If any wires, bulbs, or shades are damaged, do not use the product.
- Connect the string lights to the power source only after they are fully installed and securely hung.
- Ensure that the power source can handle the total power consumption of the connected string lights.
- Keep the string lights away from flammable materials, liquids, and gases.
- Do not allow children or pets to play with or near the string lights.

### Installation:

- Choose the desired location for your string lights, considering the available power source and the desired aesthetic effect.
- Install the first string securely by attaching it to a support structure using hooks, clips, or appropriate hanging mechanisms. Ensure the string is taut and properly aligned.
- If connecting additional strings, use the provided connectors and avoid exceeding the maximum limit of 3 connected strings.
- Connect the plug to a compatible power outlet once the string lights are securely installed.

### Operation:

- Plug the adapter into the power source. The lights will turn on once the connection is made.
- Avoid touching the bulbs or shades while they are lit, as they may become hot.

### Maintenance:

- Before cleaning or performing any maintenance, disconnect the string lights from the power source.
- Gently clean the bulbs and shades with a dry, soft cloth. Do not use abrasive cleaners or solvents.
- Store the string lights in a dry and protected area when not in use.

### Troubleshooting:

If you encounter any issues with your LED outdoor string lights, follow these steps:

- Check the power connection and ensure it is securely plugged into a working outlet.
- Inspect the bulbs for damage or loose connections.
- Confirm proper securing of connectors if multiple strings are connected.
- If the issue persists, refer to the warranty information or contact our customer support for further assistance.