


# Dining table S

## INSTRUCTION MANUAL



**IMPORTANT: READ THIS INSTRUCTION CAREFULLY BEFORE PROCEEDING.**

This manual will provide you with clear and detailed instructions on how to safely and correctly assemble and maintain your Dining table, to ensure it brings you enjoyment.

**FOLLOW US ON**

 @abbapatio







 @abbapatio

 @Abba\_Patio

 @abbapatio\_official







# PARTS LIST


Make sure all parts listed below have been included in your package.

REF	PART NAME	QTY
<b>A</b> 	Tabletop	1
<b>B</b> 	Table Leg	4
<b>C</b> 	Screw	8+2
<b>D</b> 	Washer 1	8+2
<b>E</b> 	Washer 2	8+2
<b>F</b> 	Hex Key	1

# ASSEMBLY

## Table leg assembly

- A** x 1 
- B** x 4 
- C** x 8 
- D** x 8 
- E** x 8 
- F** x 1 



**1A)** Fix the table leg **B** to the tabletop **A** with screw **C**, washer 1 **D** and washer 2 **E**. Using hex key **F**.

## IMPORTANT INFORMATION

**IMPORTANT! Read this information before proceeding.**

### WARNING:

When using the dining table products outdoors, basic safety precautions should be followed to reduce unnecessary hazards, including the following:

- Adult assembly required.
- Choking hazard to children under the age of 3 years-contains small parts prior to assembly.
- Do be careful that some parts are heavy and sharp.
- Do not place the dining table in environments with flammable or caustic chemicals.
- Work well away from power lines, particularly when handling metal parts.
- Do not stand on the table, nor adopt unsafe sitting positions on it.
- The dining table should not accommodate items exceeding temperatures within the range of -4°F to 122°F (-20°C to 50°C).
- When the product is evenly loaded, the dining table holds up to 165.3 lbs (75 kg).
- Do not place items beyond the edge of the product, and prevent items from falling.
- Do not allow children to climb on or play on the product to avoid serious bodily injury caused by the falling.
- Keep children and pets away from the assembly area until the work is completed.
- Before each use, inspect the dining table for any signs of damage. Do not use if any parts are damaged, and replace worn or broken parts immediately.
- Never continue to use a product that is structurally unsound.
- Do not touch moving parts during operation.
- Keep clothing and body parts away from the dining table to prevent them from getting caught in the moving parts
- Outdoor furniture is not made to bear low temperature conditions, which are likely to alter its correct operating and its surface condition.
- Please recycle packaging where possible.

# CARE & MAINTENANCE

- The dining table is guaranteed to be free from any manufacturing defects for a period of 1 year from the date of purchase under normal use and in compliance with the operating instructions.
- The warranty is valid only in the original country of purchase. Abba Patio® reserves the right to exchange an item for a replacement part. Some parts may be replaced with newer purchase model parts as the product is improved over time.

## FRAME:

- Dust and dirt will collect on the dining table and will require periodic cleaning.
- Be sure to drain any water accumulated inside the frames. Air dry or wipe with a soft clean cloth.
- Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners.
- Protect furniture with anti-rust spray and use regularly.
- When not in use, please store the furniture in a dry place and avoid direct sunlight to prevent material aging and deformation.
- If rust appears, it can be removed with a common product such as white vinegar or citric acid, or a cloth soaked in car polish can also help you remove rust.
- Only Abba Patio® replacement parts should be used. It may be unsafe to use parts supplied by another manufacturer.

# CONTACT US FOR HELP

**Customer Service:** [customer@abbapatio.com](mailto:customer@abbapatio.com)

**Need Assistance? Call** +1 (888) 899-5617

## Hours of Operation:

**Phone Support:** Monday - Friday: 6:30 am - 4:30 pm, Saturday – Sunday: 8:30 am – 4:30 pm, PST.

**Email Support:** We are available 24 hours a day. Please allow up to 24 hours for a response.

**Note:** Our team is available to assist you during these hours. If you have any inquiries or require support outside of these hours, please leave a voicemail, send an email. We will get back to you promptly during the next available support hours. We thank you for your purchase!