



ASSEMBLY INSTRUCTIONS



For product support or inquiries, please reach out to us at harpagservice@gmail.com











PACKAGE INCLUDE




PACKAGE INCLUDE

CODE	DESCRIPTION	QTY
1	Top Panel	1
2	Bottom box	1
3	Left Side Panel	1
4	Right Side Panel	1
5	Shelf	1
6	Backplate	1
7	Fore foot Plate	1
8	Rear foot Plate	1
9	Left foot Plate	1
10	Right foot Plate	1
11	Padded Panels	2
12	Drawer Left Side Panel	2
13	Drawer Right Side Panel	2
14	Drawer Back Panel	2
15	Drawer Bottom Panel	2


PACKAGE CONTENT

M6*34mm  A x 32+2	Ø15*9.5mm  B x 32+2	Ø8*30mm  C x 16+2	Ø3.5*14mm  D x 2
12"  E x 2	Ø3.5*12mm  F x 16+2	Ø4*30mm  G x 8+1	14 x 13 x 10 mm  H x 4
Ø3*16mm  J x 6	260mm  K x 2	Ø3 *12mm  L x 4	BY213-QO22  M x 1


How to use the cam lock system




1. Screw cam bolt into panel




2. Push cam into panel - arrow feature on cam top points to panel edge



3. Align cam bolt(s) with cam(s) and insert all the way into cross-bored hole(s)




4. Rotate cam(s) clockwise 190°-230° to lock panels together




5. Panels should be tight against each other and connection should be rigid


Insert the wood dowel [C] at least half way by tapping lightly with a rubber mallet, IF NECESSARY.




STEP 1




STEP 2






STEP 3





STEP 4




STEP 5




STEP 6





STEP 7






STEP 8




STEP 9




STEP 10








STEP 11






STEP 12






STEP 13



STEP 14





STEP 15




x2

STEP 16





x2


STEP 17



STEP 18

			
(H) X4	(J) X6	(M) X1	(D) X2





**WARNING**



Children have died from furniture tipover.
To reduce the risk of furniture tipover:

- ALWAYS instal tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label.
Do not remove!