



AIR CONDITIONER

12,000 BTU WINDOW AC WITH ELECTRIC HEATER



FOLLOW ME
Portable remote control thermostat feature for total room coverage

CHOOSING

THE RIGHT SIZE AIR CONDITIONER FOR YOUR ROOM

1 MEASURE AREA OF THE ROOM

CALCULATE ROOM SIZE
room length x room width = sq. ft.

2 MATCH ROOM SIZE WITH CORRECT BTUs

ROOM SIZE (sq. ft.)	ROOM SIZE (sq. ft.)	BTUs
150	10' x 15'	5,000
250	15.5' x 16'	6,000
350	17.5' x 20'	8,000
450	18' x 25'	10,000
550	22' x 25'	12,000
700	25' x 28'	15,000
1,000	31.25' x 32'	18,000
1,500	37.5' x 40'	25,000
2,000	40' x 50'	28,500

3 CONFIRM WINDOW OPENING SIZE

MEASURE WINDOW OPENING IN INCHES
for thru-the-wall units, confirm & measure wall opening size in inches

4 CHECK ELECTRICAL REQUIREMENTS

OUTLET CONFIGURATIONS

DETERMINE IF YOUR CIRCUIT IS ADEQUATE

WINDOW AC FEATURES

- Electronic controls
- Full range air direction control
- Temperature output range of 62°F–86°F (17°C–30°C)
- Auto, Sleep, Dry & Energy Saver modes
- Full function remote control
- 24 hour timer
- Window mounting kit
- Auto restart function
- Tilt-out filter access

3PACH12000
w/ electric heater

UPC CODE	8-42149-02421-5
COOLING CAPACITY (BTU)	12,000/11,600
HEATING CAPACITY (BTU)	11,000
COVERAGE (sq. ft.)	450–550
EER	10.9
ENERGY STAR RATED	No
FAN SPEEDS (Cool/Fan/Heat)	3/3/1
AMPS (Cool)	5.0/5.2
AMPS (Heat)	15.2
WATTS (Cool)	1,100/1,064
WATTS (Heat)	3,600
DECIBELS (Hi/Mi/Lo)	61/58/55
WINDOW WIDTH (Min./Max.) (in.)	27/36
WINDOW HEIGHT (Min.) (in.)	16 ^{1/2}
UNIT DIMENSIONS (WxHxD) (in.)	22 ^{3/4} x 16 ^{1/4} x 23 ^{1/4}
PKG. DIMENSIONS (WxHxD) (in.)	25 ^{1/4} x 17 ^{1/4} x 28 ^{1/2}
STUFFING QTY. (20'/40'/40' HQ)	135/270/324
WEIGHT (Net/Gross) (lbs.)	84/99
REFRIGERATION	R410A
OUTLET CONFIGURATION	20 AMP 230V



PA/SS_3PACH12000/05022019

5401 Dansher Road
Countryside, IL 60525

866.996.9255
630.323.2301

www.perfectaire.us
support@perfectaire.us