

150 WATT MAXIMUM TYPE A 3-WAY BULB (NOT INCLUDED)

ASSEMBLY INSTRUCTIONS

1. FASTEN SOCKET ASSEMBLY(B) ONTO LAMP BASE(A), BE CAREFUL NOT TO TWIST THE POWER CORD, TIGHTEN SECURELY.
2. PLACE HARP(C) ONTO SADDLE, PLACE SHADE(D) ONTO HARP(C)
3. TIGHTEN FINIAL(E).

WARNING

DO NOT USE POLISHER OR CLEANERS ON YOUR LAMP JUST CLEAN WITH SOFT CLOTH.

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG(ONE BLADE IS WIDER THAN THE OTHER). AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG, IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED.

