

Acrylic Tray Care Instructions

Our acrylic furniture and accessories are designed to last a lifetime with minimal care and maintenance. To keep your purchase looking new, simply wipe it clean as needed. But, care should be taken to avoid scratches.

CAUTION:

- Never use window cleaner, ammonia products, or other chemical sprays on acrylic.
- Use a soft clean damp cloth when cleaning acrylic surfaces.
- It is possible to scratch acrylic, so NEVER use any scouring compounds or chemical cleaners (no Windex or other glass cleaners even if they are environmentally friendly, organic or non-scented).
- Do not use any specialty solvents to remove stickiness or glue.
- Scratches can happen. Unlike other materials, scratches on acrylic can be removed with specialty acrylic polish.