
Dining Chair




Please read these instructions fully before starting assembly:

- 1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
- 2. Kindly follow the assembly instructions step by step.
- 3. Do not tighten all screws and bolts until the table is fully assembled.
- 4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
- 5. Parts of the assembly will be easier with 2 people.


Care and maintenance:


Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.




ASSEMBLY INSTRUCTIONS Part List A \bigcirc BACK FRAME (4 pcs) SEAT FRAME (4 pcs) **(C** LEG LEFT (4 pcs) LEG RIGHT (4 pcs) (E) LEFT SIDE STRETCHER (4 pcs) RIGHT SIDE STRETCHER (4 pcs)

ASSEMBLY INSTRUCTIONS Hardware List 1 2 Ø 1/4" x 40mm Ø 1/4" x 55mm BOLT (8pcs) BOLT (16 pcs) 3 (4)Ø 1/4" x 75mm Ø5/16" x 13mm BOLT (16 pcs) FLAT WASHER (40 pcs) <u>(5)</u> 6 Ø5/16" x 19mm 4mm ALLEN KEY (1pc) LOCK WASHER (40 pcs) Ø4 x 38mm WOOD SCREWS (16 pcs)





STEP 3:



BOLT	FLAT WASHER	LOCK WASHER	ALLEN KEY	WOOD SCREWS
Ø 1/4" x 55 mm	Ø5/16" x 13 mm	Ø5/16" x 19mm	4 mm x 75mm	Ø4 x 38mm
_	a			_
0	Ø			<i>⊕</i>

COMPLETE

