


How to use remote control?



You can choose 1-4 massage parts(back,lumbar,thighs,legs)to enjoy

How to Only Keep The Heat Work: Turn on the massage and heat firstly, and then press one of the 4 buttons(back, lumbar, thigh, leg) twice, then the massage will be turned off.

ON/OFF:Turn on/off remote control

HEAT:Turn on/off heat function for lumbar part only

INTENSITY:Control massage funcion from low to high

MODE:Choose one massage mode you like(pulse,press,wave,auto,normal)