ASSEMBLY INSTRUCTION

We believe you will absolutely love your new furniture. Please immediately examine this product carefully. Any request for missing part or damage replacement must be received within 90 days of your receipt of the product. For some reason you want to return the product, please contact us directly before you decide to return your product to the retailer. Our Customer Service team can answer most concerns and can assist you with any questions you may have about your new product.

Replacements for missing or damaged parts or hardware are normally shipped within 3 to 5 business days and we thank you for your patient.

The item must be returned in good condition, in original box, with all original proof of purchase, parts and accessories, within the time frame specified by the retailer it was purchased from.

90-Day Limited Warranty Statement for Manufacturing Defects

Please read this Limited Warranty carefully. To maintain your Warranty, you will need to comply with the conditions stated here. This warranty is for manufacturing defects only and does not cover damages as a result of misuse.

1. Our products sold comply with the description contained in this Warranty. All parts and products are warranted 90-Day from the original date of delivery except: parts and products used for commercial, contract, rental trade, institutional, or any other non-residential purposes; parts and products that have not been maintained in accordance with the care recommendations provided; parts and products damaged resulting from the consumer's improper assembly; or parts and products that are damaged or defective due to normal wear and tear.

2. To exercise rights under this warranty, proper documentation, i.e., photography, purchase order number, manufacturer's bar code label, and or any other pertinent information upon request is required. We reserve the right to repair or replace the product within the warranty period based upon the documentation received as support of a claim for consideration. We will not replace or repair any product if improper maintenance, improper handling, or improper use caused the damage. Any product sold from or modified by a Non-Authorized Dealer, Seller or Consumer will void the Warranty.

3. Cost of packaging and shipping to and from us is not covered by the warranty unless expressly arranged by us. This warranty does not extend to furniture that has been exchanged or replaced by us as settlement of an original claim of defective merchandise. This warranty does not extend to furniture that has been moved from delivery location on original purchase order.

We appreciate your business!

ASSEMBLY INSTRUCTION

PARTLIST

1  HEADBOARD CUSHION x1	2 FOOTBOARD CUSHION x1	3 FOOTBOARD LEG x2	4 SIDE RAIL x2
5 SIDE RAIL x2	6  SIDE RAIL LEG x2	7  SLAT WITH NUT x4	8 SLAT x8
9  SOCKET x24	10 SUPPORT RAIL x2	11  WING (R) x1	12  WING (L) x1
13 WING SUPPORT (R) x1	14  WING SUPPORT (L) x1	15 SUPPORT LEG WITH HANGER BOLT x8	16 CENTER SUPPORT x4
17 DRAWER PANEL x4	18  DRAWER x4	19 CASTOR x16	

ASSEMBLY INSTRUCTION

HARDWARE

A JCBB SCREW M8 x 70MM x4	B JCBC SCREW M6 x 15MM x8	C JCBC SCREW M6 x 20MM x8	D JCBC SCREW M6 x 35MM x10	E JCBC SCREW M6 x 45MM x4
F WOOD DOWEL M10 x 30MM x4	G SPRING WASHER M6 x 12MM x10	H FLAT WASHER M6 x 19MM x10	I SPRING WASHER M8 x 13MM x4	J FLAT WASHER M8 x 22MM x4
K L - KEY M4 x 100MM x1	L L - KEY M5 x 65MM x1	M  SUPPORT LEG ADJUSTABLE FEET x8		

HARDWARE (DRAWERS)

N  NUT x40	O JCBB SCREW M5 x 11MM x40	P  JCBC SCREW M6 x 15MM x20	Q L - KEY M4 x 65MM x1	R L - KEY M3 x 50MM x1	S SPANNER x1

ASSEMBLY INSTRUCTION

STEP 1



STEP 2



STEP 3



STEP 4



ASSEMBLY INSTRUCTION

STEP 5



STEP 6



STEP 7



STEP 8



ASSEMBLY INSTRUCTION

STEP 9



STEP 10

x2

*Top is facing up



STEP 11

x8



STEP 12



ASSEMBLY INSTRUCTION

STEP 13



STEP 14

x4



STEP 15



x4

STEP 16



x4

ASSEMBLY INSTRUCTION

STEP 17



ASSEMBLY
COMPLETED