




Cabinet

EN

Thank you for purchase on our products. Please contact us if you have difficulty with assembly or need replacement parts. Our customer service is here to assist you. Please attach your User Name or Order ID so that we can assist you better.

WARNING

Serious or fatal injury may occur from unexpected assembly or use.

1. During the assembly process, keep all parts away from babies or children.
2. Always securely fix this product to the wall. Make sure the wall area to be drilled is free from hidden electrical wires, water and gas pipes.
3. Use of tip-over restraints may only reduce, but not eliminate the risk of tip-over.
4. Unless specially designed to accommodate, do not set heavy objects on top of this product.
5. Place the heaviest items on the lowest shelf.
6. Never allow children to climb or bang on drawers, doors or shelves.

DE


Vielen Dank für Ihren Kauf von uns Produkten. Bitte kontaktieren Sie uns, wenn Sie Probleme mit Montage haben oder Ersatzteile benötigen. Wir Kundenservice ist für Sie da. Bitte geben Sie Ihren Benutzernamen oder Ihre Bestellnummer an, damit wir Sie besser unterstützen können.

WARNUNG













Bei unerwarteter Montage oder Verwendung können schwere oder tödliche Verletzung auftreten.

1. Legen Sie in den Montageprozess alle Teile weg von Babys oder Kindern.
2. Stellen Sie sicher, dass der gebohrte Wandbereich frei von verborgenen Stromkabeln, Wasser- und Gasleitungen ist, wenn Sie dieses Produkt an der Wand befestigen.
3. Die Verwendung von Kippsicherungen kann die Gefahr eines Kippens nur verringern, jedoch nicht beseitigen.
4. Setzen Sie bitte keine schweren Gegenstände auf dieses Produkt, es sei denn, dass das Produkt speziell für die Unterbringung konzipiert wird.
5. Legen Sie bitte die schwersten Gegenstände auf das unterste Regal.
6. Erlauben Sie nie Kindern, auf Schubladen, Türen oder Regale zu klettern oder zu knallen.

Parts List(EN) / Teile Liste(DE)









Parts List(EN) / Teile Liste(DE)

A  M6×32mm 57+2PCS	B  Ø15×9.5mm 57+2PCS	C  Ø6×30mm 44+2PCS	D  M3.5×14mm 50+2PCS
E  M4×40mm 21+2PCS	F  M4×14mm 48+2PCS	G  L77mm 1PCS	H  8PCS
I  8+1PCS	J  7PCS	K  M4×18mm 14+1PCS	L  Ø5×17mm 8+1PCS
M  M3.5×12mm 6PCS	N  2SETS	O  3PCS	
CL  L300mm 3PCS	CR  L300mm 3PCS	DL  L300mm 3PCS	DR  L300mm 3PCS


Assembly Steps(EN) / Montageschritte(DE)


STEP 1



	D x 6PCS
	CL x 1PCS
	CR x 1PCS




STEP 2




	A x 16PCS
---	------------------

Assembly Steps(EN) / Montageschritte(DE)

STEP 3




180°



Turn over part ④ to
install the other side.

	D x 6PCS
	CL x 1PCS
	CR x 1PCS

STEP 4






Turn over part ④ to
install the other side.

	A x 6PCS
--	----------

Assembly Steps(EN) / Montageschritte(DE)


STEP 5




	D x 6PCS
	CL x 1PCS
	CR x 1PCS

Turn over part ⑤ to install the other side.

STEP 6




	A x 6PCS
---	-----------------

Turn over part ⑤ to install the other side.


Assembly Steps(EN) / Montageschritte(DE)

STEP 7




	O x 3PCS
	D x 6PCS

STEP 8




	B x 4PCS
	C x 3PCS




Assembly Steps(EN) / Montageschritte(DE)


STEP 9





	B x 4PCS
	C x 3PCS



STEP 10





	B x 2PCS
	C x 3PCS
	E x 2PCS



Assembly Steps(EN) / Montageschritte(DE)


STEP 11




	B x 2PCS
	C x 1PCS

STEP 12



Lock the long side of the "N" L-shaped metal plate to the ① board with the "M" short screw



	A x 16PCS
	M x 2PCS
	N x 2SETS


Assembly Steps(EN) / Montageschritte(DE)


STEP 13



	B x 8PCS
	C x 4PCS


STEP 14



	C x 4PCS
	E x 4PCS


Assembly Steps(EN) / Montageschritte(DE)

STEP 15





	B x 8PCS
	C x 6PCS

STEP 16



	G x 1PCS
	M x 4PCS


STEP 17





	B x 8PCS
	C x 6PCS

Assembly Steps(EN) / Montageschritte(DE)

STEP 18




STEP 19



	B x 8PCS
	C x 8PCS


Assembly Steps(EN) / Montageschritte(DE)

STEP 20



L x 8PCS


STEP 21



D x 8PCS






I x 8PCS



Assembly Steps(EN) / Montageschritte(DE)

STEP 22

Drill 2 holes on the wall at the required position for anti-falling device installation.





WALL




N x 2SETS

STEP 23

Move the cabinet to the required position, use the "E" long screw to fix the cabinet to the wall.




WALL





E x 2PCS

Assembly Steps(EN) / Montageschritte(DE)

STEP 24




x2






E x 8PCS

STEP 25



x2




A x 8PCS



B x 8PCS



C x 4PCS





J x 2PCS




K x 4PCS


STEP 26




x2



D x 12PCS





DL x 2PCS



DR x 2PCS




Assembly Steps(EN) / Montageschritte(DE)

STEP 27



E x 5PCS

STEP 28



A x 5PCS



B x 5PCS




C x 2PCS




J x 1PCS




K x 2PCS




STEP 29



D x 6PCS




DL x 1PCS




DR x 1PCS

Assembly Steps(EN) / Montageschritte(DE)

STEP 30



STEP 31




x4

	F x 16PCS
	H x 8PCS
	J x 4PCS
	K x 8PCS



Assembly Steps(EN) / Montageschritte(DE)

STEP 32

When the hinges are installed, you can refer to the pictures to adjust crevice of the doors till it's perfect:





1. To adjust the doors up and down, please refer to step (a)
2. To adjust the distance between the doors and side panels, please refer to step (b)
3. To adjust the gap between two doors, please refer to step (c)
4. After the adjustment finished, please tight the screws, refer to step (d)



F x 32PCS

STEP 33




Notice: Dear customer, if the cabinet is not stable enough, you can twist the plastic feet under the middle-leg to adjust it.


The ways to adjust the door

- Before adjusting the hinge, please check whether the cabinet is skewed.
- If the skew can not be repaired, please remove the anti-tipping device first, then adjust the cabinet to vertical position.
- Please adjust the hinge with the door open.
- Please operate it with more than 2 people, one person holds the door and the other one adjusts the screw.



Components Name



Obvious gaps between doors or Doors don't look closed



- 1 Turn "internal & external screw" to the right can make the door approach inside. Please adjust the doors little by little.




※ If the 2 doors are overlap, please turn the "internal & external screw" to the left.

When door is crooked




Please take the following steps to adjust first.

- 1 Rotate the "front and rear screws" to the left




※ After adjusting the "front and rear screw", the door still does not change, please turn the "internal & external screw" to the right slightly.


- 2 Push the door to the cabinet




- 3 Rotate the "front and rear screws" to the right




When door is leaning




- 1 Turn "internal & external screw" to the left can make the top of the door tilted outward.




Protruding to the upside




- 1 Turn "internal & external screw" to the left can make the bottom of the door tilted outward.




When the door is higher on top




- 1 Turn "up & down screw" to the left



- 2 Lower the door's height so that 2 doors are of the same height.



- 3 Turn "up & down screw" to the right



※ If the door is lower on bottom, please lift up the left door slightly on step 2

WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- **ALWAYS** install Anti-tip device provided.
- For use with televisions weighing 30 lb or less. Use with heavier televisions may result in instability causing tip-over resulting in death or serious injury.
- **NEVER** allow children to stand, climb or hang on any drawers, doors, or shelves.
- **NEVER** open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

***This is a permanent label.
Do not remove!***