

ASSEMBLY INSTRUCTIONS



BOOKCASE

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

40 MINUTES


PARTS IDENTIFICATION

A SIDE PANEL




2PCS

D RIGHT SHELF




4PCS

B TOP AND
BOTTOM PANEL




2PCS

E BACK PANEL



1 PC

C LEFT SHELF



4PCS





HARDWARE IDENTIFICATION

Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	5	BOLT Ø9.5x55mm SR		12PCS
2	WOODEN DOWEL Ø8x30mm		40PCS	6	SCREW Ø4.3x35mm SR		8PCS
3	CAM LOCK Ø15x12mm SR		16PCS	7	STICKER Ø20mm		7PCS
4	CAM BOLT Ø7x35.5mm SR		16PCS				

NOTE:



Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

STEP 1





Apply glue on all wooden dowels to ensure integrity of the structure.



STEP 2





STEP 3



STEP 4








STEP 5



Apply glue on all wooden dowels to ensure integrity of the structure.

STEP 6





Note : Dimension tolerance $\pm 5\%$

ANTI-TIPPING INSTALLMENT INSTRUCTIONS

FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.
This restraint may protect against tipping furniture.
Do not allow children to climb on furniture.
This restraint is not a substitute for proper adult supervision.
Failure to detach this restraint before moving the furniture
may result in injury and damage.

1. To attach the anti-tip strap, securely mount one end to the top of the case piece with the 5/8" screw.
2. Position the case piece against the wall in the desired location.
3. Pull the anti-tip strap taut and mark the position of where you will secure the other end on the wall.
4. Drill a 1-1/4" hole in the spot you marked.
5. Tap in plastic wall plug.
6. Fasten anti-tip strap with wall screw provided.

(Please install the anti-tipping kit in the middle of the case piece if only have one set of anti-tipping kit.)

