

Keep children and others safe by following these simple rules:

- When assembling, do not let children play around the working area.
- Keep small parts and packaging away from children.
- Do not allow children to climb or play on the product.



Read and save this instruction for future use



NOTES:

- Please check contents before assembly. If any parts are missing or damaged, please feel free to contact us via buyer-seller message system and we will provide you with satisfactory solutions.


- This dog crate requires Two Adults for assembly.

- Do not fully tighten screws until assembly is complete: Especially when installing the door locks, avoid fully tightening the screws until all parts are assembled.

- Please avoid using power tools, such as power drills, during assembly. They may overtighten screws, leading to stripped threads.




01




1. Place Top Panel A face down on the floor. Align Side Panels B and C so that the circled through holes face the same side of Top Panel A. Then attach Side Panels B and C to Top Panel A using Screw ①

02




2. Secure Metal Bar D (designed to add extra strength) to Back Panel E using Screw ②. Then carefully align the ends of Metal Bar D with the two through holes in Side Panels B and C using Screw ②.

03



3. Connect Back Panel E to Side Panels B and C using Screw ②. **Carefully rotate the entire product so that one Side Panel is facing down and the other one is facing upward.** This position will make it easier to attach Bottom Panel F to Back Panel E using Screw ②.

04



4. Use Screw ② to attach Front Door Panel G to Bottom Panel F, Side Panels B and C. Then install leg levels ④.