


# Installation & Troubleshooting Manual


## Before Installation:

- Please do not install any dimmer switch, but it is available to use a simple "on/off" wall switch with the remote.
- If you purchased the dimmable ceiling fan and are willing to install a dimmer switch, please do not install this remote. It does not acknowledge installing both controls at the same time.

## Installation & Function



- Light ON/OFF
- Power ON/OFF
- 1/2/3/4/5/6 Speed / Fan ON
- Fan OFF
- Color Temperature
- SETUP SET UP MODE
- NIGHT MODE
- Color Temperature
- Brightness
- F/R Fan Reversible
- 2H+ Timing 2H  
(Repeat according to the superposition duration)



Note: The battery for the remote controller is not included under the safety concern in transit, please use model# "AAA" battery.

\*For several ceiling fans, please press the the turn off/on button quickly, the light tone will change immediately.

## Re-Program:

Use the wall switch to turn on the light, the long-press SETUP button will automatically correct the code within 10 seconds when the power is on.

Then please try the remote again.