

ASSEMBLY INSTRUCTION


Thank you for purchasing the quality product. sure to all packing material carefully for small parts which may have come loose inside the carton during shipment. Seperate, identify and count all parts and metal hardware. Compare with all parts list to be sure all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.

***** Do not fully tighten screws until fully assembled *****

COMPONENT PARTS			
"NO"	DESCRIPTION		Q'TY (PCS)
①	Chest		1
②	Front legs		2
③	Back legs		2

HARDWARE REQUIRED

Ⓐ		Middle Bolt	ϕ5/16″X2″	8	PCS
Ⓑ		Lock Washer	⌀5/16″X12mm	8	PCS
Ⓒ		Flat Washer	ϕ5/16X19mm	8	PCS
Ⓓ		Allen Wrench	**5mm**	1	PCS
Ⓔ		Fasten unit	44mmX20mm	4	PCS
Ⓕ		Long Screw	Ø7mmX38mm	4	PCS
Ⓖ		Short Screw	Ø6mmX16mm	4	PCS
Ⓗ		Shrink bolt	Ø5/16"X1-1/2"	4	PCS
Ⓘ		Safty belt	8mmX250mm	2	PCS



How to assemble:

