














# ASSEMBLY INSTRUCTION


## 26"W BOOKCASE

<b>A</b> Top	<b>B</b> Side Frame-LSF	<b>C</b> Side Frame-RSF	<b>D</b> Shelf
			
1pc	1pc	1pc	3pcs
<b>E</b> Lower Frame	<b>F</b> Tension Bar	<b>G</b> Bolt 1/4"*5/8"	<b>H</b> Bolt 1/4"*7/8"
			
1pc	2pcs	5pcs	20pcs
<b>I</b> Allen Wrench 4MM	<b>J</b> Nut 1/4"	<b>K</b> Open Wrench 10MM	<b>L</b> Anti-Tipping HW
			
1pc	1pc	1pc	2sets




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


- 
- 1** Attached top(A), side frame-LSF(B), shelves(D), lower frame(E) with bolts(H) by allen wrench(I).




- 
- 2** Attached side frame-RSF(C) with bolts(H) by allen wrench(I).



- 3** Attached tension bar(F) with bolts(G), nut(J) by allen wrench(I) and open wrench(K).



- 4** Attach anti-tipping hardware(L) to wall. Attach bracket (vertically) to wall using 2 of the screws provided. Move furniture to its final position. Thread the strap through bracket, pull it tight.



### Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.