

材质: 105g铜版纸

尺寸: 90\*120 mm

印刷: 单黑双面印刷

装订方式: 折页

## User Manual

LED Floor Lamp

### Introduction

Thank you for choosing our floor lamp. Please read this user manual carefully and keep it for future reference. If you need any assistance, please contact us with your order number and details.


### Package Contents

- LED Bulb x1
- Remote control x1
- Lamp base x1
- User Manual x1
- Iron Pipes x5
- Two Shade and Two Metal Ring x1
- AAA Batteries x2


### Specification

|                    |                     |
|--------------------|---------------------|
| MODEL              | MF18559.6           |
| LAMP               |                     |
| Material           | Metal + Fabric + PC |
| POWER              | MAX 60W             |
| Input Voltage      | AC120V 60HZ         |
| Size               | D10.24" X H62.4"    |
| Bulb               |                     |
| Power              | MAX 9W              |
| LUMINOUS FLUX      | 800LM               |
| DIMMABLE           | 10%-100%            |
| Color temperature  | 3000K-6000K         |
| Lifespan           | 30000H              |
| Battery of Control | AAA X2              |
| Remote Distance    | MAX49.2 ft          |
| Input Voltage      | AC120V 60HZ         |

### Product Structure



### Installation



Carefully remove all parts from the box and remove all plastic coverings

Step ①-③: Insert all the poles through screw side by side as the image on the left

Step ④: Tape the Velcro of the lamp shade, make it a circle

Step ⑤: Install the single iron loop on the bottom

Step ⑥: Install the double iron loop on the top, the small loop down side

Step ⑦: Put the double lamp shade through the base


Step ⑧: Screw the screw ring to the bulb base through the bottom of the shade (unscrew from the base firstly)

Step ⑨: Screw the E26 based bulb to the lamp base

### Usage

There are two ways to control: Foot switch control/Remote control

#### Foot switch ON/OFF



#### Remote Control

- Ⓜ Set a 1h timer (Light get several flickers mean 1h timer is successful set)
- Ⓜ Short press to turn on/off light.
- ☀ Short/Long press to enhance the CCT (3000K to 6000K) as you like.
- ☾ Short/Long press to lower the CCT (6000K to 3000K) as you like.
- ☀ Short press to be the max brightness and CCT immediately.
- \*+ Short/Long press to enhance the brightness as you like.
- \*- Short/Long press to lower the brightness as you like.
- Ⓜ Short press to Adjust Color Temperature 3 Levels.
- 📖 Short press to enter reading mode.
- 👤 Short press to enter breastfeed mode.
- 🌙 Short press to enter night light mode.
- 🏢 Short press to enter work mode.

### When can you use the remote control?

A 9w 800Lumens intelligent bulb is included in the package. You may use regular bulb to replace the intelligent bulb if you prefer that. Please note that regular bulb cannot match the remote control. Need to repair the remote control and bulb if you replace one of them. Please check the repair method below.

Foot switch is the prerequisite for remote control. Make sure you have turned on the lamp with the foot switch when you using the remote for turning on/off, changing the CCT, modes and timer. Remote control cannot be used if foot switch is turning off status.


### How to repair the remote control and the bulb if the remote is not working?

Long press the 'Ⓜ' button on the remote control and turn on the lighting by foot switch at the same time. When you see the bulb flashes, it means the matching process is completed and you can use the remote now.

Please contact us if the remote still doesn't work after this.

### How to adjust the lighting angle?

60 degree adjustable at the lamp holder:



### Product Care

- Please do not bend violently the lamp head to avoid damage when adjusting the angle of the lamp.
- Please read the user manual before use.
- Suggest indoor use. It is non waterproof. Do not use this product in humid environments or at high temperatures.
- Cut off the power when cleaning it or not using it.
- Do not use it exceed the voltage, the proper voltage for US is AC110-120V,60Hz.
- Please stop use it if there is any defective issues found in the product.

### Guarantee

our standing floor lamp is backed by 12MONTHS product warranty. For questions, assistance, or support, please contact the Customer Service with your order number and product model number. We will send you future information about the return or the exchange.