

Installation & Assembly

Black Fitness Desk



Fits a variety of treadmill models and is compatible with styles that are between 26.8 to 34-inches-wide.



The laptop desk attaches to your treadmill using adjustable hook and loop closure straps for a secure fit. Adjust hooks according to the space between treadmill arms. Use velcro loops to secure desk to treadmill.

Customer Service

If you have any question about assembly, use or possible missing part, please contact us and we will be glad to assist you.