


FSC
www.fsc.org
100%
Wood from well-managed forests
FSC® C183324

Armless Chair
Assembly Manual




CAUTION THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Parts


A  Backrest	B  Armless Chair	C  Plastic Leg x 4

Before you begin


Locate the Plastic Legs (C) at the bottom of the Armless Chair Seat.




Step 1: Tip over the Armless Chair, remove the 4 Plastic Legs (C), align them with the holes as shown, and tighten the Plastic Legs by hand.



Step 2: As shown in the figure, pull the headrest hinge mechanisms until they are fully upright. Then attach the backrest Velcro firmly to the back frame and zip up the zipper.




Step 3: Snap the metal part of the headrest into the raised hinge, ensuring it is firmly locked in place, as illustrated in the figure. Then fasten the hook-and-loop strips (Velcro®-type) located underneath the back cushion to the corresponding strips on the seat base.




How to Connect

Step 1: Lift the side of the sofa with the protruding side brackets, insert it into the side slots on the opposite side, to lock them into place.



Step 2: For Power Armless Chair, connect the wires piece by piece.



Step 3: Plug the power cord of either the left or right power armchair into the power outlet.

Note: After all the connections are made, the green LED will be lit up.

