
ASSEMBLY INSTRUCTION

58" TV stand





THIS INSTRUCTION BOOKLET IS IMPORTANT. PLEASE READ CAREFULLY.
AND KEEP FOR FUTURE REFERENCE.



Before You Start

- ⚠ Please read all instructions carefully.
- A Retain instructions for future reference.
- Read through each step carefully and follow the proper order.
- We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- Always place the product on a flat, steady and stable surface.
- Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.





| PACKAGE CONTENT (A) | | |
|---------------------|--------------------------|-----|
| CODR | DESRIPTION | QTY |
| 1 | Countertop Board | 1 |
| 2 | Middle Partition | 1 |
| 3 | Upper Lateral Plate | 2 |
| 4 | Top Vertical | 2 |
| 5 | Laminates | 1 |
| 6 | Upper Back Panel | 1 |
| 7 | Middle Leg | 1 |
| 8 | Lower Left Side Plate | 1 |
| 9 | Lower Right Side Plate | 1 |
| 10 | Lintel Strip | 1 |
| 11 | Center Bar | 1 |
| 12 | Storage Shelf | 2 |
| 13 | Lower Back Panel | 2 |
| 14 | Left Medial Side Plate | 1 |
| 15 | Forefoot Strip | 1 |
| 16 | Left middle front block | 1 |
| 17 | Right middle front block | 1 |
| 18 | Cabinet Door | 2 |

| PACKAGE CONTENT (B) | | |
|---------------------|-----------------------------|-----|
| CODR | DESRIPTION | QTY |
| 19 | Right Medial Side Plate | 1 |
| 20 | Bottom Plate | 1 |
| 21 | Left Leg | 1 |
| 22 | Back Leg | 1 |
| 23 | Right Leg | 1 |
| 24 | Middle back panel | 1 |
| 25 | Middle activity layer board | 1 |

