

CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.

The use of steam or water-based cleaners may cause excessive shrinking or staining.













NOTICE

* Please make sure that you have all parts indicated before you begin assembly of this item

* This item should be assembled on a soft surface to prevent scratching the finish during assembly

* This item may require periodic tightening

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
1	Sofa Back		1X
2L	Sofa&Chair Side Panel 1		3X
2R	Sofa&Chair Side Panel 2		3X
3	Chair Back		2X
4	Sofa Bottom		1X
5	Chair Bottom		2X
6	Table Apron		2X
7	Table Side Panel		2X
8	Table Top		1X
A	Allen bolt(M6x35 mm)		42X
B	Flat washer		42X
C	Allen key		1X


OUTDOOR LIVING SET

Product Dimensions:




20.5"x26.8"x29.5" H (Chair)

42.9"x26.8"x29.5" H (Sofa)




35.4"x19.7"x12.6" H (Table)






3






4 x2





5 x 2




6 x2



7



(A) x12

 M6 x 35mm

(B) x12
