
Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY OOOODIFFICULT

Tools Required For Assembly:

Allen Wrench



Phillips Screwdriver







ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.



Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor. No dragging of products/parts.



Some furniture comes with height adjusetment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Parts List



Headboard Cushion

#2 x 1pc Footboard

> #3 x 2pcs Side Rail

#4 x 3pcs Bed Slat w/o marking 1545 x 45 x 18mm

#5 x 2pcs
Bed Slat with marking
1545 x 45 x 18mm


#6 x 5pcs Bed Slat Support 82 x 30 x 30mm

#7 x 5pcs Concealed Panel 2040 x 295 x 9mm

Hardware List



#A x 5pcs Bolt 1/4" x 2"



#B x 4pcs Bolt 5/16" x 2-3/4"



#C x 8pcs Flat Washer



#D x 4pcs Wing Nut M8



#E x 1pc Allen Key m4




#F x 1pc Allen Key m5




#G x 10pcs CSK m4 x 32mm

#H x 25pcs P.H Screw m3.5x20mm




Page 4 of 6




Page 5 of 6




This is how the concealed panels (#7) look like on the bed from a high view.





Page 6 of 6

Assembly Instructions



ASSEMBLY RATING


The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY O O O O DIFFICULT

Tools Required For Assembly:

Allen Wrench

Phillips Screwdriver







ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.



Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor. No dragging of products/parts.



Some furniture comes with height adjusetment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Parts List



#1 x 1pc

Headboard Cushion



#2 x 1pc

Footboard



#3 x 2pcs

Side Rail



#4 x 3pcs Bed Slat w/o marking 1845 x 45 x 18mm



#5 x 2pcs Bed Slat with marking 1845 x 45 x 18mm



#6 x 10pcs Bed Slat Support 82 x 30 x 30mm





#7 x 4pcs Concealed Panel 2164 x 295 x 9mm

Hardware List



#A x 10pcs





#B x 4pcs

Bolt M8 x 70mm



#C x 8pcs

Flat Washer



#D x 4pcs

Wing Nut M8



#E x 1pc

Allen Key m4



#F x 1pc

Allen Key m5




#G x 10pcs

CSK m4 x 32mm




#H x 30pcs


P.H Screw m3.5x20mm




Page 4 of 6




Page 5 of 6





Page 6 of 6

Assembly Instructions



ASSEMBLY RATING


The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY OOOODIFFICULT

Tools Required For Assembly:

Allen Wrench

Phillips Screwdriver







ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.



Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor. No dragging of products/parts.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Parts List



Headboard Cushion



#2 x 1pc Footboard

#1 x 1pc



#3 x 2pcs Side Rail




#4 x 3pcs Bed Slat w/o marking 1951 x 45 x 18mm



#5 x 2pcs Bed Slat with marking 1951 x 45 x 18mm




#6 x 10pcs Bed Slat Support 82 x 30 x 30mm




#7 x 6pcs Concealed Panel 2040 x 295 x 9mm

Hardware List



#A x 10pcs Bolt 1/4" x 2"



#B x 4pcs Bolt 5/16" x 2-3/4"



#C x 8pcs Flat Washer



#D x 4pcs Wing Nut M8



#E x 1pc Allen Key m4




#F x 1pc Allen Key m5




#G x 10pcs CSK m4 x 32mm



#H x 30pcs P.H Screw m3.5x20mm



Page 4 of 6



Page 5 of 6

