
ASSEMBLY INSTRUCTIONS:

- 1. Carefully unpack the carton and then lay out all the parts on the flat surface.
- 2. Insert the Harp (B) into saddle of lamp body (A).
- 3. Put shade on harp (B), and then put Plastic washer (C), make the shade keep horizontal before tightening it by finial (D).

Note: The direction of finial should match the body (A), see the picture shown.



Your lamp now is ready to enjoy

Use 150 Wattage (Maximum) 3 Way Type A bulb (Bulb not included)

IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.