

INSTALLATION INSTRUCTIONS

LED OUTDOOR WALL SCNCE

120VAC Input, Dimmable

READ AND FILLW SAFETY INFORMATION

Turn off the main power at the circuit breaker before installing and servicing the fixture to prevent possible injury from electric shock.

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections, obtain the services of a qualified electrician.

INSTALLATION & ASSEMBLY

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

1. Place the mounting wall plate(3) over the outlet box(1), align themounting slots of the wall plate with holes of the outlet box as shown. Use a level to ensure the wall plate(3) is straight.
2. Mark the location of the keyhole slots of the wall plate on the wall. Drill a ¼” holes at the narrow end of each keyhole slot marking on the wall. Carefully hammer a wall anchor into each drilled hole.
3. Pull the supply wires (4 &5) and house ground wire (6) out from the outlet box (1) before attaching wall plate to outlet box. Make electrical connections, connect the black fixture wire (9) to the black supply wire (5) and contect the white fixture wire (10) to the white supply wire (4) by using wire nut (7). Connect the fixture ground wire (10) to the supply ground wire (6) together by using wire nut (7). Wrap all wire connections with electrical tape to ensure secure connection.
4. Place the fixture body (11) over the mounting wall plate (2) and secure it to the wall plate by using rubber shim(12), stainless steel shim(13) and fixture screws (14) .
5. After installing the fixture, caulk upper 2/3 of wire connection enclosure to mounting surface. Leave bottom 1/3 un-caulked for drainage of any water that might leak into the enclosure. The manufacturer recommends a non-drying exterior caulking material. A good example is a clear silicone rubber sealant for exterior use.

6. Installation complete, restore power at the circuit breaker and turn light switch on to activate this fixture.

Care and maintenance – Use dry and clean cloth to wipe the surface of the fixture.

Replacement- This LED product has no bulb to replace.

