



Assembly Instructions

Makeup Vanity


Model:





Please check all parts and accessories according to the parts list before assembling, make sure all contents are sufficient and in good condition. If there are any parts missing or defective, please contact us immediately to get replacement parts.



Parts list


		
❶ X 6	❷ X 10	❸ X 5


Hardware List

			
❶ M6*50(*50+2)	❷ 50*50(*3)	❸ (*2) ST3*35(2) ST4*12(2)	(*1)
			
X1			

Step 1


A


 x 5



Step 2


A


 x 5



Step 3


A


 x 5



Step 4

A


 x 5



Step 5

A


 x 5



Step 6


A


 x 5



Step 7


A


 x 5



Step 8

A


 x 5



Step 9

A


 x 5



Step 10

A

 x 5




Step 7

B




x 3




Step 8

C



x 2



AFTERSALE SERVICE

Dear customer,

Thank you so much for purchasing the product from us.

We aim to provide the best shopping experience to our customers and hope that our products could meet your needs and expectations.

The package would be out of our control during shipping. Please contact us through your purchasing channel directly if there is anything wrong with the box or contents. We are always here, offering you our service.

We will reply to your messages within 12 hours. Please kindly wait for the response from our professional service team.

Your comfort and contentment are of utmost importance.

Best Regards,

Customer Service Team

MAINTAINANCE & WARNING

- 1, Never let liquids or damp cloths sit on this furniture.
- 2, Never use chemical cleaning products. They can damage the finish. For cleaning, use only a slightly damp cloth and wipe dry.
- 3, To avoid dulling of the finish, do not place furniture in direct sunlight.
- 4, Do not put plastic or rubber rings under appliances. Use cloth of felt protectors.
- 5, To clean, use a soft or slightly damp cloth, then wipe with a clean, dry cloth.

Serious or fatal crushing injuries can occur from a furniture tip-over.

To help prevent tip-over:

- 1, Place heaviest items in the lowest drawers.
- 2, Do not set TVs or other heavy objects on the top of this product. Never allow children to climb or hang on drawers, doors, or shelves.
- 3, Never open more than one drawer at a time.
- 4, Always monitor your child's activity when in the nursery.
- 5, Do not allow standing in drawers.
- 6, Do not allow standing on top of this product.
- 7, Accessory Items must be securely fastened to this product according to the instructions provided with those items.
- 8, To avoid head injury, do not allow children to play underneath open drawers.
- 9, Do not leave drawers open when not in use.
- 10, Use of tip-over restraints reduce, but does not eliminate, the risk of tip-over

Category 1

Important Safety Information – Tip-Over Hazard

This furniture is freestanding and may pose a tip-over hazard if not properly secured. To reduce the risk of serious injury or death, especially to children, this product must be anchored to a wall using the provided anti-tip hardware.

Always install the supplied anti-tip device according to the instructions before use.

Place the furniture on a flat, stable surface.

Do not allow children to climb, stand, or hang on drawers, doors, or shelves.

Do not overload drawers or place heavy items on the top of the furniture.


Never open multiple drawers at the same time.

In Case of Tip-Over or Instability:

If the furniture becomes unstable, tilted, or falls, keep children and pets away immediately. Check for damage before reusing. Reinstall or replace the anti-tip hardware if necessary. Discontinue use if the product is damaged.

Failure to follow these instructions may result in serious injury or property damage.

⚠ WARNING



Children have died from furniture tipover.

- ALWAYS secure this furniture with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture



This is a permanent label. Do not remove!