












# ASSEMBLY INSTRUCTION


## CHAISE LOUNGE WITH CUSHION

<b>A</b> Bench seat  1pc	<b>B</b> Bench arm  1pc	<b>C</b> Bench back  1pc	<b>D</b> Legs  4pcs	<b>E</b> Round pillow  1pc
<b>F</b> Back pillow  2pcs	<b>G</b> Bolt 5/16"*1-1/4"  8pcs	<b>H</b> Lock washer 5/16"  8pcs	<b>I</b> Flat washer 5/16"  8pcs	<b>J</b> Allen wrench 5/16"  1pc




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

- 1** Attached legs (D) to the bench seat (A) with bolt (G) , lock washer (H), flat washer (I), tighten with allen wrench (J).




- 2** Insert the arm (B) and back arm (C) to the bench seat (A) as shown.




---

**3** Put the round pillow (E) and back pillow (F) to the bench as shown.



---

**4** The assembly is complete .



---

#### Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.