

STEP 1

Mark the drilling position on ceiling with the help of the Mounting Bracket(A). Drill holes on the marks and stick the expansion anchors into the holes. Fix the Mounting Bracket(A) to the expansion anchors with self-tapping screws.

STEP 2

Thread the wire of Fixture Arm(B) to the hole of Lamp Support Plate(C), and screw the Fixture Arm(B) to the Lamp Support Plate(C). Repeat the above step to fix the other Fixture Arms(B).

STEP 3

Connect wire color Black/Red from the Lamp Support Plate(C) as one strand of wire. Connect wire color White/Blue of Lamp Support Plate(C) as the other strand.

STEP 4

Thread the wire of Lamp Support Plate(C) to the Canopy(D), and fix the Lamp Support Plate(C) to the Canopy(D).

STEP 5

Hold the fixture close to ceiling. Connect live line to wire color Black/Red from the Canopy(D). Connect neutral line to wire color White/Blue from the Canopy(D).

STEP 6

Attach the Canopy(D) to the Mounting Bracket(A).

STEP 7

Place the Acrylic Diffuser(E) to the Fixture Arm(B).

Your fixture is now assembled and ready to use.