


WARNING:

>This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.

>DO NOT allow children to climb on unit.

>Put heavier items on lower shelves.



Assembly Instruction

4 Tier Flexi Rack


DIMENSION : 23.6"(W) x 48.1"(H) x 11.7"(D)

00:30


Approx. 30 minutes















Recomm. 1 Person




Tool Required



NO	HARDWARE LIST	QTY
1	ROUND POLE 	8pcs
2	ROUND LEG 	4pcs
3	TOP CAP 	10pcs
4	ROUND RING 	6pcs
5	SMALL ROUND LEG 	6pcs
6	C/B SCREW 	8pcs
7	MINI FIX + HOUSING 	8pcs
8	DOWEL 	8pcs

NO	PARTS LIST	QTY
A	TOP PANEL 	1pc
B	BOTTOM PANEL 	1pc
C	SHELF PANEL 	3pcs
D	SIDE PANEL 	4pcs



USEFUL HINTS BEFORE YOU START:

1. Read each step carefully before starting.
2. It is important that each step is performed in correct order to avoid difficulties.
3. Identify, sort and count the parts before assembly.
4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
5. Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
6. Using incompatible hardware might cause damage to product.

