



Assembly Instructions




Installation of Cams and Pins












Screw the pin into the hole. To set the cams correctly, ensure that the arrow on the cam is opening to the hole of the pin it is locking. Lock the cam by turning the cam head with a screwdriver until it is tightened. Please do not use an electric screwdriver to assemble the unit.










Read each step carefully before starting. It is very important that each step of instruction is performed in the correct order. If these steps are not followed in sequence, assembly difficulties will occur.




Parts & Hardware List


 1 4pcs	 2 1pc	 3 2pcs
 4 2pcs	 5 8pcs	 6 2pcs
 7 2pcs	 8 2pcs	 9 2pcs
 10 2pcs	 11 2pcs	 12 1pc
 13 1pc	 14 1pc	 15 1pc

Parts & Hardware List


 A 2pcs	M7X50MM  B 48pcs	 C 2pcs
M6*40  F 2pcs	M6*10  M 32pcs	 W 1set
M8  Y 8pcs	 Z 2pcs	




2





3




4




5




6




7






8



9




Carefully remove the plastic film behind the light strip



You can also choose to fix the light with screws

10



11

