


KIDS SOFA

User manual



⚠ WARNINGS


- Please read the following instructions and warnings carefully.
- Keep this instruction manual for future reference.
- Do not use this product if it is damaged or broken.
- Do not change the specifications, modify this product, or use it for any other purpose beyond its intended use.
- Incorrect assembly can cause a product to fail and cause personal injury.
- Remove all packaging before first use. Please allow 46-72 hours for the foam to fully expand and slipcover wrinkles to smooth .
- This product is intended for children ages 36 months and up, with a weight limit of 30 kgs.
- Exercise caution when children are near or sitting on the sofa. Do not allow children to jump on the sofa. There is a risk of injury from not following these warnings.
- Keep all packaging away from children. There is a risk of choking and suffocation.

Care Instructions :


- Secure hook and loop closure before washing.
- Machine wash cold, gentle cycle.
- Do not bleach.
- Tumble dry, delicate. DO not Iron.




Parts




1 Sofa Assembly-Arrangement 1




2 Sofa Assembly-Arrangement 2




3 Sofa Assembly-Arrangement 3




4 Sofa Assembly-Arrangement 4



5 Sofa Assembly-Arrangement 5



6 Sofa Assembly-Arrangement 6



Let imagination run wild. Multiple combinations waiting to be explored.