There are levelers underneath the Console which can be adjusted to compensate for uneven flooring. If the furniture wobbles, determine which corner does not touch the floor correctly. With two people follow these steps:

- 1. Carefully elevate the item slightly to provide access to the levelers attached to the bottom.
- 2. Turn the levelers until adequate contact will be made with the floor. Gently set down the piece and check stability.

Repeat steps until furniture sits firmly on the floor.