




COMPONENT LIST - ARMCHAIR ×2

Item no.	Reference Image	Description	Qty.
A		Back	1
B		Right Armrest	1
B1		Left Armrest	1
C		Seat Base	1
G1		Side Panel	1
E		Back Cushion	1
F		Seat Cushion	1
L1		M6*35 Head Cap Screw	8
L2		M6*30 Head Cap Screw	5

COMPONENT LIST - ARMCHAIR ×2

Item no.	Reference Image	Description	Qty.
L3		M6*65 Head Cap Screw	2
M		Washer	15
N		Allen Key	1

NOTE:



Do NOT tighten any screws fully first until you have tightened all the screws.

This may cause the frame to warp.

If there is still wobbles or screw holes cannot be aligned, loosen the screws and tighten sequentially.



If the Sofa is not stable it could lead to damage to the product.

01



NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

02



NOTE: DO NOT TIGHTEN THE SCREWS COMPLETELY.

03

(L2)





M6*30 Screw ×3

(M)



Washer ×3



NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

04

(L1)



(L2)





(L3)



(M)




M6*35 Screw x3 M6*30 Screw x2 M6*65 Screw x2 Washer x7




NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

05 Tighten all 15 Screws into place with Allen Key.







NOTE:IF ANY SCREW HOLES CANNOT BE ALIGNED, LOOSEN ALL THE SCREWS AND GO BACK STEP 1 AND RESTART ASSEMBLY.


06



COMPONENT LIST - LOVESEAT

Item no.	Reference Image	Description	Qty.
A1		Back	1
B		Right Armrest	1
B1		Left Armrest	1
C1		Seat Base	1
G		Side Panel	1
E		Back Cushion	2
F		Seat Cushion	2
L1		M6*35 Head Cap Screw	9
L2		M6*30 Head Cap Screw	6

COMPONENT LIST - LOVESEAT

Item no.	Reference Image	Description	Qty.
L3		M6*65 Head Cap Screw	2
M		Washer	17
N		Allen Key	1

NOTE:



Do NOT tighten any screws fully first until you have tightened all the screws.

This may cause the frame to warp.

If there is still wobbles or screw holes cannot be aligned, loosen the screws and tighten sequentially.

If the Loveseat is not stable it could lead to damage to the product.

01



NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

02

(L1)





M6*35 Screw ×5

(M)



Washer ×5



NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

03

(L2)




M6*30 Screw ×4


(M)



Washer ×4



x4



x4

NOTE: DO NOT TIGHTEN THE SCREWS COMPLETELY.

04

(L1)



(L2)




(L3)



(M)




M6*35 Screw x3 M6*30 Screw x2 M6*65 Screw x2 Washer x7




NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.

05 Tighten all 17 Screws into place with Allen Key.





NOTE:IF ANY SCREW HOLES CANNOT BE ALIGNED, LOOSEN ALL THE SCREWS AND GO BACK STEP 1 AND RESTART ASSEMBLY.

06



COMPONENT LIST - TABLE

Item no.	Reference Image	Description	Qty.
O		Table side Panel	2
P		Table side Panel	2
J		Table Glass	1
L1		M6*35 Head Cap Screw	8
M		Washer	8
N		Back Cushion	1
Q		Adjusting Foot	4

NOTE:



Do NOT tighten any screws fully first until you have tightened all the screws.

This may cause the frame to warp.

If there is still wobbles or screw holes cannot be aligned, loosen the screws and tighten sequentially.



If the Table is not stable it could lead to damage to the product.

01



NOTE: DO NOT TIGHTEN THE SCREWS COMPLETELY.

02



NOTE:DO NOT TIGHTEN THE SCREWS COMPLETELY.