


USE AND MAINTENANCE


- Use on level surfaces only
- Because this product needs assembly, it is prone to working itself loose from time to time depending on the use. Please take the time to check that all connections are still tight and working properly for safety.
- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

Deluxe Adjustable Recliner


PART LIST



1 - Seat Back×1




2 - Base×1




3 - Ears×2

Assembly Instructions

①




②



Slide the 3(×2) onto the brackets on the 1.


Lower the 1 on the 2 and make sure the brackets are completely aligned. Lock the brackets by pushing down on the 1. You will hear a clicking sound when the brackets are properly secured.

③




Pull the back cover down and press against the Velcro tape firmly. Simply push the Seat Back(A) to set yourself in motion. Congratulations! It's time to enjoy.

④



The control switch lifts and lowers the seat.



Congratulations! Setup of your new Deluxe Adjustable Recliner is Complete!
Keep these instructions for future reference.

If you need help or have damaged or missing parts, contact customer service

All Rights Reserved.