


ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Phillips
Screwdriver

(Not Included)



2 - People
Recommended

ASSEMBLY RATING



EASY ————— DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING



Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.



Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!



Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.




Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.























Save the instructions and store
any supplied tools for later
maintenance.

Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

| Carton | Disignation | Part | | Hardware |
|--------|----------------------------|------|--------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | Arm (2pcs) | #1 |  |  #A x 8pcs  #B x 4pcs  #C x 8pcs  #D x 20pcs  #E x 16pcs  #F x 4pcs  #G x 75pcs  #H x 4pcs  #I x 1pcs |
| | Plastic feet (4pcs) | #11 |  | |
| | Top Back Panel | #2 |  | |
| | Top Side Rails(2pcs) | #3 |  | |
| | Bottom Front Panel | #4 |  | |
| | Bottom Back Panel | #5 |  | |
| | Bottom Side Panels (2pcs) | #6 |  | |
| | Top Slat (13pcs) | #7 |  | |
| | Bottom Slat (12pcs) | #8 |  | |
| | Top Center Support Rail | #9 |  | |
| | Bottom Center Support Rail | #10 |  | |

DAY BED




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

#1 2pcs



Arm(L&R)

#2 1pc



Top Back Panel

#3 2pcs



Top Side Rails

#4 1pc




Bottom Front Panel

#5 1pc




Bottom
Back Panel

#6 2pcs




Bottom
Side Panels

#7 1Set



Top Slat
(13pcs)

#8 1Set



Bottom Slat
(12pcs)

#9 1pc



Top Center
Support Rail

#10 1pc



Bottom Center
Support Rail


#11 4pcs



Plastic feet


HARDWARE

#A 8pcs




Bolt Ø5/16" x 1-1/2"

#B 4pcs



Bolt Ø5/16" x 2-1/2"

#C 8pcs




Bolt Ø5/16" x 3/4"

#D 20pcs



Spring Washer
Ø5/16"

#G 75pcs




Screw #8 x 32mm

#E 16pcs



Flat Washer
Ø5/16"x19mm

#H 4pcs




Screw #8 x 50mm

#F 4pcs




Flat Washer
Ø5/16"x22mm

#I 1pc




Allen Key 5mm



ASSEMBLY INSTRUCTIONS

1


Part **#1** x1pc
Part **#11** x2pcs
Hardware **#H** x2pcs



Align Plastic feet (#11) to the headboard (#1), then secure by using screws (#H).

2

Part **#3** x2pcs
Hardware **#A** x8pcs
Hardware **#D** x8pcs
Hardware **#E** x8pcs




Align side rails (#3) to the arms (#1), then secure by using bolts (#A) with washers (#D,E).

ASSEMBLY INSTRUCTIONS

3

Part #9 x1pc

Align and attach support rail (#9) to arms (#1).



4


Part #2 x1pc

Hardware #B x4pcs

Hardware #D x4pcs

Hardware #F x4pcs

Align back panel (#2) to the arms (#1), then secure by using bolts (#B) with washers (#D,F).




ASSEMBLY INSTRUCTIONS

5

Part #7 x1set
Hardware #G x39pcs


Align slats (#7) to the side rails (#3),
then secure by using screws (#G).



6

Part #4 x1pc
Part #5 x1pc
Part #6 x2pcs
Hardware #C x8pcs
Hardware #D x8pcs
Hardware #E x8pcs

Align side panels (#6) to the front and
back panel (#4,5). Secure by using bolts
(#C) with washers (#D,E).




ASSEMBLY INSTRUCTIONS

7

Part **#10** x1pc


Attach support rail (#10) to the side panels (#6).



8


Part **#8** x1set
Hardware **#G** x36pcs

Align slats (#8) to the side panels (#4,5), then secure by using screws (#G).




ASSEMBLY INSTRUCTIONS

9



10



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.