


ASSEMBLY INSTRUCTION

ITEM NO.N715P406514

Dining Chair



ASSEMBLY INSTRUCTION

ITEM NO.N715P406514

Please read these instructions fully before starting assembly:


1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the table is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

ASSEMBLY INSTRUCTION

ITEM NO.N715P406514




ASSEMBLY INSTRUCTION

ITEM NO.N715P406514


Part List

Ⓐ




BACK FRAME (4 pcs)

Ⓑ



SEAT FRAME (4 pcs)

Ⓒ




LEG (8 pcs)

ASSEMBLY INSTRUCTION

ITEM NO.N715P406514

Hardware List


①



Ø 1/4" x 40 mm

BOLT (8 pcs)


②



Ø 1/4" x 55 mm

BOLT (16 pcs)

③



Ø 1/4" x 75 mm

BOLT (16 pcs)


④



Ø5/16" x 13 mm

LOCK WASHER (40 pcs)

⑤



Ø5/16" x 19 mm

FLAT WASHER (40 pcs)

⑥




4 mm

ALLEN KEY (4 pcs)

ASSEMBLY INSTRUCTION


ITEM NO.N715P406514

STEP 1:



BOLT Ø 1/4" x 40 mm	BOLT Ø 1/4" x 75 mm	LOCK WASHER Ø5/16" x 13 mm	FLAT WASHER Ø5/16" x 19mm	ALLEN KEY 4 mm x 75mm
				
① x 8	③ x 16	④ x 24	⑤ x 24	⑥ x 1

STEP 2:



BOLT Ø 1/4" x 55 mm	LOCK WASHER Ø5/16" x 13 mm	FLAT WASHER Ø5/16" x 19mm	ALLEN KEY 4 mm x 75mm
			
② x 16	④ x 16	⑤ x 16	⑥ x 1

X2

ASSEMBLY INSTRUCTION

ITEM NO.N715P406514

COMPLETE

