


ASSEMBLY INSTRUCTIONS


Read this instruction carefully. Refer hardware and furniture parts list		PART LIST			HARDWARE LIST		
for guidance. Be sure all parts are complete, before assembling. Place all	ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY	
wooden furniture part on a clean and flat soft surface to prevent scratcheds. Refer steps provided as assembling guide.	Α	HEADBOARD	1 PC	1	BOLT X 70MM CCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCC	© 4 PCS	
	В	SIDERAIL (L & R)	2 PCS	2	HEX NUT M6	4 PCS	
CAUTIONS : 1.Do not FULLY-TIGHTEN the nuts or nut bolts until all are in place. 2.To prevent thread damage.Ensure that nuts or nut bolts are not over-tighten. 3.Hardware are to be kept out of reach from children.	C	FOOTBOARD	1 PC	3	PLASTIC WASHER	4 PCS	
	D	BED LEG	4 PCS	4	JCBC M6 X 45MM	15 PCS	
	E	CENTER RAIL	1 PC	5	SPRING WASHER	15 PCS	
	F	SLAT	13 PCS	6	FLAT WASHER (O)	12 PCS	
	G	LEG SUPPORT	3 PCS	7	L-BRACKET(BLACK)	2 PCS	
	L			8	M4 ALLEN KEY (SHORT)	_ 1 PC	
	11	CSK SCREW X 32MM	26 PCS	9	SPANNER CC	1 PC	
	12	WOOD DOWEL DIA 8 X 35MM	8 PCS	10	CSK SCREW X 20MM <******	8 PCS	


STEP 1











ASSEMBLY INSTRUCTIONS

Read this instruction carefully. Refer hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling. Place all wooden furniture part on a clean and flat soft surface to prevent scratcheds. Refer steps provided as assembling guide.

CAUTIONS :

Do not FULLY-TIGHTEN the nuts or nut bolts until all are in place.
To prevent thread damage.Ensure that nuts or nut bolts are not over-tighten.
Hardware are to be kept out of reach from children.

