


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY



DIFFICULT

Tools Required For Assembly:

Allen Wrench



(Included)

Phillips Screwdriver



(Not Included)




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.



Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor. No dragging of products/parts.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.



Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List




#1 x 1pc
Headboard (LED)



#2 x 1pc
Headboard Leg (L)



#3 x 1pc
Headboard Leg (R)




#4 x 1pc
Footboard




#5 x 2pcs
Bun Foot



#6 x 2pcs
Side Rail




#7 x 2pcs
Drawer




#8 x 2pcs
Drawer Base Panel




#9 x 1pc
Drawer Support Rail




#10 x 13pcs
Roll Slat




#11 x 1pc
Center Vertical Slat



#12 x 3pcs
Slat Support Leg (short)



#13 x 1pc
Slat Support Leg (Long)




#14 x 1pc
Drawer Support Leg




#15 x 1pc
Slat Cover Panel



#16 x 2pcs
Top Cap



#17 x 1pc
Slat



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Hardware Pack in Headboard




#A x 1pc
Allen Wrench



#D x 6pcs
M6 Flat Washer



#B x 6pcs
JCBC 35mm



#E x 1pc
AC Adapter



#C x 6pcs
M6 Lock Washer

Hardware Pack in Side Rail



#F x 1pc
Allen Wrench



#K x 16pcs
M8 Flat Washer



#G x 16pcs
JCBC 5/16" x 20mm



#L x 11pcs
M6 Lock Washer



#H x 1pc
JCBC 35mm



#M x 10pcs
M6 Flat Washer




#I x 10pcs
JCBC 45mm




#N x 2pcs
Screw 32mm



#J x 16pcs
M8 Lock Washer




#O x 1pc
Adjustable Leveler




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Hardware Pack in Footboard




#P x 1pc
Allen Wrench



#X x 26pcs
Screw 32mm



#Q x 2pcs
JCBC 16mm



#Y x 4pcs
Adjustable Leveler



#R x 9pcs
JCBC 35mm



#S x 3pcs
JCBC 60mm



#T x 14pcs
M6 Lock Washer



#U x 7pcs
M6 Flat Washer



#V x 4pcs
1/4" Flat Washer




#W x 2pcs
Screw 16mm



#B x 6pcs
#C x 6pcs
#D x 6pcs
#E x 1pc




Ensure adapter socket
connect to behind
Headboard socket



L1
#2

Lighting touch switch
(Left & Right)



R2

#3


#E

Prepare 6 bolts assembly by inserting lock washer (#C), then flat washer (#D) onto bolts (#B). Align left HB leg (#2) and right HB leg (#3) to the holes of the headboard (#1) as shown in the diagram. Secure by using bolts (#B).



Remove Bun Foot from
the carton


Remove Bun
Foot cover



#4

#4

#5




Secure the (#5) Bun Foot to
the bottom of (#4) Footboard
as a diagram shown.




Prepare 16 bolts assembly by inserting lock washer (#J), then flat washer (#K) onto bolts (#G). Secure the half of bolts to the HB Leg & Footboard, align and hook side rails (#6) to the bolts of the headboard (#1) and footboard (#4) as shown in the diagram. Tighten all bolt & make sure it is firmly secured.

#G x 16pcs
#J x 16pcs
#K x 16pcs



#Q x 2pcs
#T x 2pcs
#U x 2pcs




Prepare 2 bolts assembly by inserting lock washer (#T), then flat washer (#U) onto bolts (#Q). Align drawer support rail (#9) to the holes of the side rails (#6). Secure by using bolts (#Q).



Make sure to fully extend rails to see the black switch on the rails.



Step to remove the drawer :

1. Pull the drawer
2. Using both hands,
 - Left hands side - pull up switch
 - Right hands side - pull down switch
3. Than remove the drawer from the drawer base panel




#R x 8pcs
#T x 8pcs
#U x 4pcs
#V x 4pcs

Prepare 4 bolts assembly by inserting lock washer (#T), then flat washer (#U) onto bolts (#R). Align drawer base panels (#8) to the holes of the drawer support rail (#9). Secure by using bolts (#R).




Prepare 4 bolts assembly by inserting lock washer (#T), then 1/4" flat washer (#V) onto bolts (#R). Align drawer base panels (#8) to the holes of the footboard (#4). Secure by using bolts (#R).





#R x 1pc
#T x 1pc
#U x 1pc
#Y x 1pc


Prepare 1 bolt assembly by inserting lock washer (#T), then flat washer (#U) onto bolts (#R). Align drawer support leg (#13) to the back hole of the drawer support rail (#9), then secure by using bolts (#R). Attach adjustable leveler (#Y) to the bottom of the support leg (#14), then adjust leveler according to ground level.



Step to install the drawer on the drawer base panel :

***Prefer 2 person to install the drawer

1. Adjust the ball bearing plate to the front as a diagram shows.
2. Than attach the drawer to the dawner base panel and install with carefully.





Insert the drawer (#7) to the footboard (#4)

Align and connect the rails of the drawer base to the drawers.



#S x 3pcs
#T x 3pcs
#Y x 3pcs
#X x 26pcs

Align slats (#10) to the side rails,
then secure by using screws (#X).





Prepare 3 bolts assembly by
inserting lock washer (#T) onto
bolts (#S). Attach levelers (#Y)
onto the support legs (#12) and
adjust leveler according to
ground level. Align center
vertical slat (#11) and support
legs (short) (#12) to roll slats
(#10) holes, then secure by
using bolts (#S).



#H x 1pc
#L x 1pc
#O x 1pc
#N x 2pcs


Align slats (#17) to the side rails,
then secure by using screws (#N).



Prepare 1 bolt assembly by
inserting lock washer (#L) onto
bolts (#H). Attach levelers (#O)
onto the support legs (long)
(#13) and adjust leveler
according to ground level.
Then secure by using bolt (#H).



#W x 2pcs



#I x 10pcs
#L x 10pcs
#M x 10pcs

