






Assembly guide

Prepare To Start




Components

Part1	1x
Part2	1x
Part3	1x
Part4	2x
Part5	1x
Part6	1x
Part7	1x
Part8	1x
Part9	1x
Part10	1x
Total	11x




Accessory Parts

A01



Dowel Q816x

A02



Screw16x

A03




Head16x

A04



Rafix Screw4x

A05




Rafix Head4x

A06




Pvc Sticker16x

A08




Nail20x

A09




Allen1x

A15



Leg2x

A16



Piston2x

A17




3,5 x 16 Screw48x

A28



Hinge Base4x


A29




Flat Hinge4x

How to instal Components

*Before starting, please check the below figures



HEAD




SCREW




DOWEL


If the dowel is not required during the installation phase, it is not included in the package.




*Please notice that there is an small arrow on A03 (head). This arrow should show the direction of upper hole.




*After attaching two pieces please turn the A03 (head) other clockwise direction with the help of a screwdriver




*Please do not over screw the head since it may be broken if too much power is imposed. Just make sure that it is screwed to the direction "+" do not go any further.




1.




2.




3.




4.




5.




6.







7.



8.



9. Settings of Hinge



10.

