


# ASSEMBLY INSTRUCTIONS

1. CAREFULLY UNPACK AND LAY OUT THE PARTS AS SHOWN IN ILLUSTRATION.
2. SCREW THE CONNECTOR ( B ),POLE ( C ),POLE ( D ) SOCKET PART ( E ) ONTO THE BASE ( A ) IN TURN.
3. PUT THE HARP ( F ) INTO THE SOCKET PART ( E ).
4. PUT THE SHADE ( NOT INCLUDED ) ONTO THE HARP ( F ) AND SCREW IT TIGHTLY BY FINIAL ( G ).

YOUR LAMP NOW IS READY TO ENJOY

USE 3-WAY 150W WATTAGE ( MAXIMUM ) TYPE  
A



## IMPORTANT SAFETY INSTRUCTIONS :

THIS PORTABLE LAMP HAS A POLARIZED PLUG ( ONE BLADE IS WIDEER THAN THE OTHER ) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT,CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE