

ASSEMBLY INSTRUCTION

DE - MONTAGEANWEISUNG

FR - INSTRUCTIONS DE MONTAGE

DK - MONTAGEVEJLEDNING

CZ - NÁVOD K MONTÁŽI

ES - INSTRUCCIONES DE MONTAJE

FI - ASENNUSOHJE

HR - UPUTE ZA MONTAŽU

SE - MONTERINGSANVISNING

SI - NAVODILA ZA MONTAŽO

TR - MONTAJ TALIMATI

NO - MONTASJEANVISNING

IT - ISTRUZIONI DI MONTAGGIO

GR - ΟΔΗΓΙΑ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ

NL - MONTAGE INSTRUCTIE

PT - INSTRUÇÕES DE MONTAGEM

PL - INSTRUKCJA MONTAŻU


HU - SZERELÉSI UTASÍTÁS



25 min




0 cm
1
2
3
4
5
6
7
8
9
10
11
12
13
14



x 2

HW-ST-01-046
(7 x 90)



x 2

HW-ST-02-021
(6 x 20)



x 4

HW-ST-02-031
(6 x 45)




x 4

HW-ST-03-019
(6 x 20)




x 2


HW-ST-18-001
(4 x 98)



A x1
SU-SC-ST-0145



B x1
SU-SC-LF-0228



C x1
SU-SC-LF-0229



D x1
SU-SC-SP-0025

