

EASY TO INSTALL

① Gently twist the roof



② Remove insulation tab



③ Turn on the switch



④ Pull and connect the spike



⑤ Connect the pole



⑥ Complete

