

Maintenance

1. At the beginning of each season and at least twice monthly during usage, treat ropes with a Teflon-based lubricant.
2. Before each use, check the rope, knots, support and all connections for evidence of deterioration, excessive wear, fractures, breaks or sharp edges and replace as necessary.
3. Take tire swing indoors when the temperature drops below 32 degrees Fahrenheit.

WARNING: Failure to carry out these checks and inspections could result in a fall or injury.

NOTE: The color swings fade in natural condition is normal phenomenon

Operation Instructions

1. An adult should supervise play on this product for children of all ages.
2. Limit: 1 child per swing.
3. Only for family domestic outdoor use by children 3-8 years old.
4. Dress children appropriately, including wearing well-fitting shoes that fully protect the feet.
5. Instruct children to:
 - Avoid swinging empty seats or swings.
 - **NEVER** swing higher than hook attachment.
 - To get off the swing only after it has completely stopped and to hold the rope until both feet are planted firmly on the ground.
 - To remove articles before playing on equipment that create hazards when they get tangled and caught. Examples include: ponchos, scarves, and other loose-fitting clothing, bike or other sports helmets.
 - **DO NOT** walk close to, in front of, behind, or between moving items.

Tire Swings Instruction

For all Tire Swings:
Pooky, Shmoopie, Winky

Installation

1. Do not install tire swing over concrete, asphalt, packed earth, or any other hard surface.
2. Confirm that the supporting structure is secure; it will support at least 200 pounds, is over level ground, and is no less than 6 ft. from vertical elements on all sides.
3. Tree Limb Assembly
 - Test tree limb to ensure that it will hold the weight limit of 200 lbs. safely.
 - Form a small noose at one end of your rope and throw it over the tree limb.
 - Run the other end of rope through the noose you created and tighten firmly.
 - Run the end of rope through the loop on the tire swing.
 - Tie a minimum of TWO tight knots firmly. Bottom of swing should be no less than 8 inches from ground.



Swing Set or other Horizontal Beam Assembly

Attach the tire swing to a swing set by removing one set of chains from an existing swing and attach the upper loop (above the PVC separator bar) to the chain support hook on the underside of the swing set crossbar. Then close the hook.

