

Care and USE

Thank you for your purchase.

We recommend hand washing to best preserve the work and encourage the following best practices:

- Avoid using scouring pads and/or abrasive detergents which can cause unnecessary wear on the glazes.

- To preserve the longevity of your ceramics, we recommend avoiding using abrasive dishwashing detergents and to let each piece dry completely before storing.

- Do not expose to sudden, dramatic shifts in temperature.

- Extreme heat or extreme cold can cause damage and cracks.

- Most stains can be removed by soaking the item in warm water before washing.

If you have any questions about our products, please contact our support team: 973-394-9300.

Have a Nice Day!