

Assembly Instructions

Before you begin...

1. Please check you have received the correct product.
2. Unpack all boxes and lay out each component on the floor.
3. Check your product for any damage that may be immediately obvious. If damage is identified, please contact your retailer.
4. Please read through these instructions thoroughly to ensure you have constructed your **chair** correctly.

For Care and Maintenance of your **chair**...


- Always assemble in your desired room of use.
- Always check all screws and fixings periodically to ensure they are still secure.
- **Do not push or pull this chair as it will cause damage.**
- Always lift this chair with a second person to prevent damage or injury.
- Keep any sharp objects away from this chair.

For your Health and Safety...

- Please don't not jump on this **chair**.
- **Do not use this chair if you find missing, damaged or worn parts. Please contact your retailer.**
- Please do not use this chair until you have fully secured all fixings.
- Please keep all small components away from children.
- Please ensure this chair is on an even, level surface.


Also...

If your desired room of choice has a non-carpeted surface please ensure that you use some form of protection and do not place directly on the wooden floor. This will prevent the chair from moving and therefore collapsing which will void your guarantee..




Box 1


All fittings are stored within the zipped compartment under the seat.



A.Chair Frame(x1)



B.Front Legs(x2)



C.Back Legs (x2)



D.Plastic Washer (x4)

Step 1

Turn the 1 x chair frame (A) over to access the bottom of the product. Remove all components from the zipped compartment under the seat. Attach the 2 x Front legs (B) and 2 x Plastic washer (D) to the front corners of the chair and 2 x Back legs (C) and 2 x Plastic washer (D) to the back corners of the chair.

