


INSTRUCTION MANUAL

ASSEMBLY GUIDE

Congratulations, you now have a new function sofa with massage.

Before enjoy the comfort chair,you have to put it together.This Assembly Guide will take you through the basic assembly process.To make sure your assembly goes smoothly,please follow the assembly instructions, and especially the important safety information.


Also, while it is possible to assemble the chair on your own, having a second person to help you makes it even easier.

Before you begin, please check if there are any missing parts from the package. Should there be any issues, please don't hesitate to drop us an email and we'l help you out ASAP.

PACKAGE LIST

Seat cushion


L



Ⓐ*1

Seat cushion


R



Ⓐ*1

Back


L



Ⓑ*1

Back


R



Ⓑ*1

Seat frame


L



Ⓒ*1

Seat frame


R



Ⓒ*1

Armrest cover


L



Ⓕ*1


Armrest cover

R



Ⓕ*1

Massager remote control board




Ⓖ*2

Massager power supply




Ⓗ*2

Back frame




Ⓣ*2

Connector



Ⓤ*4

Bolts
M6*16mm




Ⓝ*8+1(extra)

Spanner




Ⓞ*1

Cup holder




Ⓟ*2

Glove



Ⓠ*1


Pillow




Ⓦ*2

PACKAGE LIST

STEP 1: Flip the seat frame over with the footrest facing upwards,Pull the footrest with your hand, Then remove the compressed back and the accessory box from the frame.




STEP 2: Open the compression bag and remove the armrest cover.




ASSEMBLY INSTRUCTION

STEP 3: Open the compression bag and remove the armrest cover.




STEP 4: Fix the connector to the inside of the armrest with M6x16mm bolts, paying attention to the direction of fixing the connector.




ASSEMBLY INSTRUCTION

STEP 5: Fix the connector to the inside of the armrest with M6x16mm bolts, paying attention to the direction of fixing the connector.




STEP 6: Place the cup holder into the groove.




ASSEMBLY INSTRUCTION

STEP 7: Insert arms so that they can fit into the seat,you will hear a“click” when they are engaged.




STEP 8: Repeat Step 7.




ASSEMBLY INSTRUCTION

STEP 9: Open the compression bag and remove the seat cushion.




STEP 10: Pull the inner hand ring to open the foot plate, Open seat bag A, stick the Velcro on the footboard, and stick the Velcroon the seat bag.(Note: The cushion can be adjusted repeatedly to avoid improper pasting affecting the sitting feeling and the use of the pull ring)




ASSEMBLY INSTRUCTION

STEP 11: Open the compression bag and remove the back.




STEP 12: Zip the backpack and back frame, and then connect the backpack and back frame with velcro gently pat them.




ASSEMBLY INSTRUCTION

STEP 13: Zip the backpack and back frame, and then connect the backpack and back frame with velcro.gently pat them.




STEP 14: lug the back pad into the seat frame, and then connect the massager line white and white, red and red, black and power lines, and the massage line with the hand controller.




ASSEMBLY INSTRUCTION

STEP 15: Hang the pendant on the pendant slot, and the two chairs can be connected together.




STEP 16: Stick the velcro from the back frame to the seat frame.




Congratulations!You've assembled


Your Sofa!



OPERATING INSTRUCTION



Pull the handle to spread out the SOFA




Pull back the SOFA with your legs

MASSAGE CHAIR

READ ALL INSTRUCTIONS
BEFORE USING THE ITEM

REMOTE CONTROL

Function of remote



Massage Intensity Levels

Massage duration

ON/OFF

Intensity button:Click to cycle and switch vibration intensity; when turned on, the default intensity setting is M gear.

Timer button

Heating button:Press to activate the heating function, press again to deactivate the heating function.

Mode selection button:Click to cycle and switch the vibration mode, with the default mode at startup being M4.

Massage mode

Massage area

Ⅰ、Specifications of power adapter

The power is on in the standby state. The user can activate the function via the hand controller.

nput:AC100-240V,50Hz/60HZ;Output:DC12V1A.

Ⅱ、Product features

1、8 points massage

2、One-way switch for independent heating plate operation

3、Three-segment timing, with a default shutdown time of 10 minutes.

4、Three levels of vibration intensity

5、5 vibration modes

Ⅲ、Function details

1、Switch on and off

2、TIME: Cycling through massage durations (10/20/30min). Default startup is 10 minutes.

3、MODE: Tap the five vibration modes to switch (M1/M2/M3/M4/M5).The default startup mode is M4

4、INT: Switch intensity by vibration strength(H/M/L). Default startup is M(medium).

5、HEAT: Click to toggle heating.

6、PART: Vibration positioning key.Default startup is full vibration; tap to switch to single-part vibration.

7、Massage Intensity Levels

8、Massage duration

9、Massage mode

Warnings

- Sit down in the char geutly. To avoid tipping over, do not throw yourself into the chair. Move the chair unio the recliming position slowly, making sure that no childres or pets are un close proximity.
- Do not allow childree to play on or around the chair, purticulauly when it is in am opeu posstion.
- Close the recliner completely before getting out of it.
- Never sit on the fontrest when it is opem, even ifit is a child.
- To eliminate the risk of tipping over, do not sit on the atmres or footest of the chadr.
- This chair is designed to be used by 2 adhilt at a time.
- Please forbid people with the following ailments from using this sofic Those people with severe symptoms of heurt discase, high blood pressure, cerebral thrombosis and others who are sensitive to heat or completnly invensitive to hea, those with hritile bones or have issues with waist support pregaut women, children and others wher it has been deturmined they are oot suitable to uie this product under the guidance of docters.
- To fully recline the sofa, ensure the sofn well, you need to put the sofa at least 19 inches away from the wall or any other obstacle.
- Product cammot twwch water, fao, etc, Product can also not come in contact with sharp objects (knives, nails,(tc.)

Maintenance Manual Instrnctions

- To aveid dropping. you should carry the sofn carefully.
  If' you find dint and or stains on the chair, spmay the sofa with a sufa specific cleaner then use a sponge or cloth to wipe the ditt away.
- Do not use wader, soapy wader or cleaner with waxed wooden ascis. Take care to wipe the sofa carefiully and gently.
- Do not put the sofil in an nren with direot sumlight and do not put the snfa directly in front of an air conditioner, this will fade the upholstery and make it brittle.

How to Disassemble

Please find a strong tool to prod the small piece of metal grooves, then the backrest will be pulled out .The tool is not included.

