

ASSEMBLY INSTRUCTION

Caution : You must read this before you proceed


Care & Maintenance

- ⊘  • Not for commercial use. For residential use only.
- ✓  • Furniture may scratch floors. We recommend using furniture pads to protect your floors.
- ⊘  • Do not put hot items directly on furniture surface.
- ⊘  • Do not clean furniture with harsh cleansers or polish.
- ⊘  • Do not place furniture under direct sunlight.
- ⊘  • Do not place furniture near heating or cooling vents.
- ⊘  • Do not write on furniture without a padded barrier to protect the surface.
- ⊘  • Do not place furniture outside. For indoor use only.
- ⊘  • Stains may be removed with mild soap solution and damp cloth.
- ⊘  • Children should not climb or jump on the furniture.





- ✓  • Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in carton for hardware packs and legs.
Sets often ship in multiple boxes and may arrive a day or two apart.




DINING CHAIR
N768P489276



Parts List


Label	Picture	Description	QTY
A		Right leg	1
B		Left leg	1
C		Seat cushion	1
D		Backrest cushion	1

HARDWARE LIST


Label	Picture	Description	QTY
①		Bolt (1/4" x40mm)	2+1
②		Bolt (1/4" x55mm)	4+1
③		Spring washer (10mm)	6+1
④		Flat washer (14 mm)	2+1
⑤		Crescent washer	4+1
⑥		Allen wrench	1+1
⑦		Dowel (Ø10x40mm)	4+1
⑧		Cover sticker (Ø21mm)	4
⑨		Felt pad	2

Assembly Preparation


Before Beginning Assembly:




A



B



C



D



①x3



②x5



③x7



④x3



⑤x5



⑥x2



⑦x5



⑧x4



⑨x2



- Read instructions, cover to cover-



- Have 2 adults on hand fo assembly-



- Do not assemble on flooring of carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-

Assembly Steps


Overview



This chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the chair parts, the above picture is provided to help you put the various parts into perspective. Please read through the instructions below to familiarize yourself with the parts and steps before assembly.


CAUTION : When tightening these bolt, tighten sequentially.
DO NOT tighten any bolt fully and then towards the next one.
This would cause the frame to warp.
If there is still wobbles, loosen the bolt and execute this same process.
WARNING!! IF IT IS NOT STABLE , IT COULD LEAD TO DAMAGING THE PRODUCT.

Step 1




Remove the screws and support beams on the frame legs.

Step 2




Attach the seat cushion C to the right leg A. Using bolt ②, spring washer③, crescent washer ⑤and allen key ⑥. Do not full tighten

Step 3



Attach the backrest cushion D and left leg B to the seat cushion C and right leg A. Using dowel ⑦, bolt ②, spring washer ③, crescent washer ⑤ and allen key ⑥. Do not full tighten

Step 4




Stand the chair up. Attach bolt ①, spring washer ③, flat washer ④ into legs, backrest cushion and allen wrench ⑥. Do not full tighten.

Step 5

Cover sticker (Ø21mm)




⑧ x2




After checking the chair, if no problem, tighten all the bolts.
Place the chair on a **LEVEL SURFACE** to check for wobbles .
After inspection, attach the cover stickers ⑧ hidden the bolt holes.

Step 6



Note: If missing or fall out the felt pad, attach new one ⑨ .



Your chair is ready for use .
This chair can only be used on a flat, level surface.