














Please check that all fittings are available and in good condition before assembly.  
If you have any questions, please contact us , we will solve your problem in the first time.

## PARTS LIST

Ax1		Bx1		Cx1( R )		Dx1( L )		Ex2					
Fx1		Gx6	 M6x25mm	Hx4	 M6x48mm	Ix4	 M6	Jx2	 M6x12mm	Kx4	 M6x30mm	Lx1	


## ASSEMBLE INSTRUCTION

1




D(L) C(R)

2




A

3




Tighten the screws to 50%.

4




Tighten the screws to 50%.

4




Tighten the screws to 50%.

5




Tighten the screws to 100%.

6



Tighten the screws to 100%.

7



Adjust foot nails to make chair stable.