


ASSEMBLY INSTRUCTIONS




WARNING !





Assembly the furniture on empty carton, carpet, or rug to prevent scratches or damage.




This furniture requires 2 people to assembly.

Make sure no parts are missing or damaged before assembly.


Board Identification

Not actual size




BOARD IDENTIFICATION


Not actual size




① x1




② x2




③ x1




④ x2




⑤ x1




⑥ x1




⑦ x1




⑧ x1




⑨ x1




⑩ x1




⑪ x1




⑫ x1




⑬ x2



⑭ x1




⑮ x1




⑯ x1

BOARD IDENTIFICATION


Not actual size




17 x1




18 x1




19 x2



20 x2



21 x2




22 x2

HARDWARE LIST




A	x44+2



Ø15x9.5

B	x44+2




Ø6x30

C	x34+2




Ø5x40

D	x14+2



Ø3.5x12

E	x48+2




F	x4




Ø20


G	x44+2




H	x7+1



I	x2




J	x22+1




Ø5x16


K	x8+2



L	x1



M	x1



N	x1




CL	x2



CR	x2




DL	x2





DR	x2


Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.













STEP 1














STEP 2















STEP 3


CL
CL
CR
CR


E
E
E
7
CL
180°
flip
E
E
E
7
CR



Ø3.5x12
E
x 6
CL
CL
x 1
CR
CR
x 1


STEP 4



A
3
A
A
A
A
A
X2
A
A
2
A
A
A
6
A
A
A
A
A
9

A
x 20


STEP 5










STEP 6







STEP 7



B
C
5
C
6
B
C
B
C
8
B
B



1
2
3



Ø6x30
C
x 4


Ø15x9.5
B
x 4

STEP 8



C
8
B
6
C
C
7
5
B



1
2
3



Ø6x30
C
x 2



Ø15x9.5
B
x 2

STEP 9













STEP 10











STEP 11



Ø6x30	
C	x6

Ø5x40	
D	x 6


STEP 12




Ø6x30	
C	x 4


Ø15x9.5	
B	x 10

STEP 13







STEP 14




STEP 15







Ø6x30	
C	x 4



Ø15x9.5	
B	x 4

STEP 16







Ø6x30	
C	x 8




Ø15x9.5	
B	x 8


STEP 17







STEP 18






STEP 19






K	x 8

STEP 20





Ø3.5x12	
E	x 8




F	x 4


STEP 21






STEP 22







STEP 23




Ø4x38mm I-4	
I	x 2


STEP 24







	
A	x 8

STEP 25







STEP 26





STEP 27







STEP 28





STEP 29


17
18
9
G
Cabinet Slide arms
Drawer Slide brackets


Ø20mm
G
x 44

FURNITURE CARE AND MAINTENANCE

Medium - Density Fiberboard and Particle board

Thank you for your purchase. We want your item to last as long as possible. To ensure the product gives you years of service, please refer to this care and maintenance guide.



MAINTENANCE

· Tighten all bolts and screws again within the first 2 weeks of assembly
· Check the tightness of all bolts every 2 months, tighten them if necessary



CLEANING

· Clean the surface of the MDF (medium - density fiberboard) or PB (particle board) with a lightly dampened cloth.
· Small amount of mild soap can be used if necessary
• Dry the surface immediately after cleaning.

⚠ DO NOT use bleach or alcohol detergent to clean the surface.
⚠ DO NOT apply wood treatment on parts made with MDF and PB.
Medium - density fiberboard and Particle board will swell and distort when suffer from water damage.
Make sure to dry the furniture immediately after cleaning