


ASSEMBLY INSTRUCTION

1-DRAWER DESK

A Top



1 PC

B Left Leg




1 PC

C Right Leg



1 PC

D Left Support Leg



1 PC

E Right Support Leg



1 PC

F Long Bolt
1/4" x 7/8"



4 PCS

G Bolt
1/4" x 5/8"



14 PCS

H Spring Washer
1/4"



4 PCS

I Flat Washer
1/4"




4 PCS

J Allen Key
M4




1 PC




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

-
- 1** Insert Left Support Leg (D) to Left Leg (B) using Bolt (G) with Allen Key (J).
Insert Right Support Leg (E) to Right Leg (C) using Bolt (G) with Allen Key (J).
Note: Do not fully tighten the bolts at this step.




-
- 2** Attach metal base to bottom of the Top (A) using Bolt (G) with Allen Key (J).
Note: Do not fully tighten the bolts at this step.




3

Attach metal base to bottom of the Top (A) using Long Bolt (F), Spring Washer (H), Flat Washer (I) with Allen Key (J).

Note: Fully tighten all bolts at this step.

**4**

With assistance from your adult partners, turn the Desk right way up. Adjust the Pre-installed Levelers on the bottom of Left Leg (B), Right Leg (C), Left Support Leg (D) and Right Support Leg (E) until the Desk is level with the ground.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.