

Assembly Instructions

Caution : You must read this before you proceed

Care & Maintenance



- Not for commercial use. For residential use only.



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Stains may be removed with mild soap solution and damp cloth.




- Children should not climb or jump on the furniture.







- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

ACCENT CHAIR



PART LIST : N763P498977


LABEL	PICTURE	DESCRIPTION	QTY
A		BACKREST	1
B		CHAIR SEAT	1
C		FRONT LEG	2
D		HIND LEG	2
E		FORNT SUPPORT	1

Hardware

LABEL	PICTURE	DESCRIPTION	QTY
①		BOLT (1/4 X 60MM)	8+1
②		BOLT (1/4 X 20MM)	4+1
③		FLAT WASHER (1/4)	12+1
④		WASHER(1/4)	12+1
⑤		ALLEN WRENCH	1


Assembly Steps

Overview




THIS CHAIR HAS MULTIPLE PARTS AND MAY REQUIRE UP TO 30 MINUTES TO ASSEMBLE. TO GIVE YOU AN OVERVIEW OF THE CHAIR PARTS, THE ABOVE PICTURE IS TO HELP YOU PUT THE VARIOUS PARTS INTO PERSPECTIVE. PLEASE READ THROUGH THE INSTRUCTIONS BELOW TO FAMILIARISE YOURSELF WITH THE PARTS AND STEPS BEFORE ASSEMBLY.


STEP 1




A




B



C



D



E

Unpack and place all the parts on a clean, non-marring surface.

STEP 2


① x 4



③ x 4





④ x 4




Place the Seat (B) upside down on a flat surface and unzip the fabric cover to access the bottom section of the seat frame. Position the Legs (D) onto the rear side of the Seat (B), ensuring that all mounting holes are properly aligned. Secure using Bolts (①), Flat Washers (③), and Washers (④), then tighten with the Allen wrench (⑤) as shown in the illustration. Note: Do not fully tighten the bolts at this stage. Tighten them to approximately 80% only to allow for proper adjustment during the assembly of the remaining parts.

STEP 3





- 3.1 Insert the Front Support Bar (E) into the mounting holes on both Front Legs (C) as shown in the illustration.
- 3.2 Position the two Front Legs (C), with the Support Bar (E) already attached, onto the front side of the Seat (B). Ensure that all mounting holes are properly aligned. Secure using Bolts (①), Flat Washers (③), and Washers (④), then tighten with the Allen wrench (⑤) as shown in the illustration.
- Note: Do not fully tighten the bolts at this stage. Tighten them to approximately 80% only to allow for proper adjustment during the assembly of the remaining parts.

STEP 4




Place the Backrest (A) upside down on a flat surface. Next, position the Seat (B) onto the Backrest (A) as shown in the illustration. Make sure to align the holes on the metal brackets of all four legs with the corresponding mounting holes on the Backrest (A).

STEP 5



Place the Backrest (A) upside down on a flat surface. Next, position the Seat (B) onto the Backrest (A) as shown in the illustration. Ensure that the mounting holes on the metal brackets of all four legs are properly aligned with the corresponding mounting holes on the Backrest (A). Secure using Bolts (①), Flat Washers (③), and Washers (④), then tighten with the Allen wrench (⑤) as shown in the illustration. Note: Do not fully tighten the bolts at this stage. Tighten them to approximately 80% only to allow for proper adjustment during the assembly of the remaining parts.

STEP 6




Place the chair on a flat surface to ensure the entire chair structure is properly aligned. Once all parts have been correctly positioned and aligned, fully tighten all bolts to 100%. Make sure all chair legs are in full contact with the floor and that the chair is stable and secure.

Note: If the chair is not properly aligned or feels unstable, loosen all bolts and repeat the alignment process before tightening them again.

Next, zip up the fabric cover underneath the seat cushion to complete the assembly process.

COMPLETED ASSEMBLY



Place the chair on a flat surface. Check and ensure that all parts are securely connected. This will help align all components correctly at the connection points.

Note 1: When tightening the screws, tighten them gradually and in sequence. Do not fully tighten any screw before moving on to the next one. Fully tightening screws too early may cause the chair frame to become warped or misaligned. If the chair still feels loose, loosen the screws and repeat the process. Again, do not fully tighten any screw before proceeding to the next.

Warning!! IF THE CHAIR IS NOT STABLE, IT MAY DAMAGE THE PRODUCT.

The adjustable levelers located underneath the chair legs can be adjusted to ensure proper balance and stability.

Ensure all screws are fully tightened.

The chair is now **READY TO USE**.

Note 2: **THIS CHAIR IS DESIGNED FOR USE ON A FLAT SURFACE ONLY.**